DESCRIPTION	SEE SEC.	NOTES
Drive Unit, Complete	38210	DPH-D
Drive Unit, Complete	38856	DPH-D1
Drive Unit, Complete	38211	DPR-D
Flywheel Housing and Primary Shaft	9750	DPH-D, DPR-D
Flywheel Housing and Primary Shaft	38830	DPH-D1
Flywheel Housing and Primary Shaft, Extended	37038	DPH-D, DPR-D
Flywheel Housing and Primary Shaft, Extended	38844	DPH-D1
Transom Shield	7750	DPH-D, DPR-D
Transom Shield	38843	DPH-D1
Exhaust Pipe and Cooling Water Pipe DPH/DPR Drive Unit, Extended	36842	DPH-D, DPR-D
Exhaust Pipe and Cooling Water Pipe DPH/DPR Drive Unit, Extended	38835	DPH-D1
Exhaust Pipe and Cooling Water Pipe DPH/DPR Drive Unit	37213	DPH-D, DPR-D
Exhaust Pipe and Cooling Water Pipe DPH/DPR Drive Unit	38857	DPH-D1
Water and Exhaust Block off Kits	6268	DPH-D, DPR-D
Gimbal Ring	36843	DPH-D, DPR-D
Gimbal Ring	38836	DPH-D1
Housing and Center Tube	38403	DPH-D
Housing and Center Tube	38838	DPH-D1
Housing and Center Tube	38417	DPR-D
U-Joint and Bearing Carrier SN-3020295797	38484	DPH-D
U-Joint and Bearing Carrier SN3020295798-	38839	DPH-D1
U-Joint and Bearing Carrier	38418	DPR-D
Upper Vertical Shaft SN-3020295797	36883	DPH-D
Upper Vertical Shaft SN3020295798-	38853	DPH-D1
Upper Vertical Shaft	38419	DPR-D
Shift Mechanism	38406	DPH-D, DPR-D
Shift Mechanism	38840	DPH-D1
Actuator	8864	DPH-D, DPR-D
Actuator	38841	DPH-D1
Drive Shaft and Bearing Housing	38408	DPH-D
Drive Shaft and Bearing Housing	38842	DPH-D1
Drive Shaft and Bearing Housing	38411	DPR-D
Jack Shaft Kit	37093	DPH-D, DPR-D
Jack Shaft Kit	38846	DPH-D1
Jack Shaft, Connecting Components	37092	DPH-D, DPR-D, DPH-D1
Rudder Indicator Kit for Drive Units	35591	DPH-D, DPR-D
Rudder Indicator Kit for Drive Units	38847	DPH-D1
Extension Kit 1"	38409	DPH-D, DPR-D, DPH-D1
Trim Pump	38431	DPH-D, DPR-D, DPH-D1
Trim Cylinders	38434	DPH-D, DPR-D, DPH-D1
Propeller	8046	DPH-D
Propeller	38848	DPH-D1
Propeller	8045	DPR-D