



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		87114A 8	EXHAUST MANIFOLD ASSEMBLY	2		
2	16	49545	STUD, MANIFOLD (1-3/4") NOT	6		
2	16	48770	STUD, MANIFOLD (3-1/2") NOT	2		
3	22	33198A 1	PLUG, EXHAUST MANIFOLD	4		
4	22	48118	PLUG, PIPE-EXHAUST MANIFO	4		
5	27	33395	GASKET, EXHAUST MANIFOLD T	2		
6	10	53728	SCREW, EXHAUST MANIFOLD (4	8		
7	22	87238	DRAIN COCK, EXHAUST MANIFO	2		
8	22	36305	ELBOW, EXHAUST MANIFOLD	2		
9	27	87105	GASKET, ELBOW (USE WITH RIS	4		
10	27	41813	GASKET, EXHAUST ELBOW (STA	2		
11	27	41811	GASKET, EXHAUST ELBOW (CLC	2		
12		98502A 2	EXHAUST ELBOW ASSEMBLY (0-	2		
12		98504A 3	EXHAUST ELBOW ASSEMBLY (1-	2		
12		44354A 3	EXHAUST ELBOW ASSEMBLY (7-	2		
13	22	36382	PLUG, PIPE-EXHAUST ELBOW	2		
14	32	58616A 2	TUBE, WATER SEPARATION	2		
15	22	45084	FITTING, EXHAUST ELBOW (STF	1		
15	22	92499	FITTING, EXHAUST ELBOW (45)	1		
16	13	35048	LOCKWASHER, MANIFOLD STUC	8		
17	11	49838	NUT, MANIFOLD STUD NOT USE	8		
18	10	43749	SCREW, MANIFOLD (5-3/4") USE	6		
18	10	44387	SCREW, MANIFOLD (6-3/4") USE	2		