



1912

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	862164T02	HARNES, Wiring	1		1
2	22	32974	FITTING, (.125-27) Adaptor	1		
3	87	805605A 1	SWITCH ASSEMBLY	1		
4	22	864669	FITTING	1		
5	87	864252	SWITCH, Oil Pressure	1		
6	87	815425T	SENDER ASSEMBLY	1		
7	13	26996	LOCKWASHER, (#10)	2		
8	11	68219	NUT, (#10-32)	2		
9		806490T	SENDER	1		
10	22	806608A 1	PLUG KIT, Blue	1		
11	25	62706	O-RING, (.426 x .070)	1		
12		805218T	SENSOR	1		
13		816492A 6	ALARM KIT	1		
14		805368T	BRACKET, Electrical	1		
15	88	806950	CIRCUIT BREAKER, (50 Ampere)	1		
16	10	68513	SCREW, (#10-32 x .375)	2		
17	13	26996	LOCKWASHER, (#10)	2		
18	10	57583	SCREW, (#8-32 x .375)	2		
19	89	96158T	SOLENOID	1		
20	10	805564	SCREW, (.250-20 x .750)	3		
21	13	26992	LOCKWASHER, (.250)	2		
22	11	94330	NUT, (.250-20)	2		
23	13	26996	LOCKWASHER, (#10)	2		
24	11	68219	NUT, (#10-32)	2		
25	85	97861	INSULATOR	1		
26		861516	BRACKET	1		
27		861255t 1	ICM MODULE	1		
28	10	24323	SET SCREW, (.250-20 x 1.25)	3		
29	12	96457	WASHER	3		
30	12	35462	WASHER, (.2656 x .625 x .0625)	3		
31	11	64015	NUT, (#8-32)	3		
32		861517	BRACKET	1		
33	10	41408	SCREW, (#10-32 x 1.50)	2		
34		806611T	MODULE, Knock Control	1		
35		806612T	SENSOR, Knock	1		
36	22	806705 1	FITTING, Dual	1		