



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	10	809902520	SCREW	12,12		
2	87	801334117	IGNITION SWITCH (SEE KEY CHZ	1,1		
3		801334100	INSTRUMENT PANEL	1,1		
4	87	801334307	CIRCUIT BREAKER	1,1		
5		801334308	COVER	1,1		
6	79	801334121	WATER TEMPERATURE GAUGE	1,1		
7	79	801334120	VOLTMETER GAUGE	1,1		
8	79	801334359	TACHOMETER GAUGE	1,1		
9	79	801334126	OIL TEMPERATURE GAUGE	1,1		
10	79	801334125	OIL PRESSURE GAUGE	1,1		
11		809978254	LIGHT BULB	6,6		
12		802982204	SOCKET	6,6		
13	87	801334110	START SWITCH	1,1		
14	87	801334114	STOP SWITCH	1,1		
15		801334326	PREHEATER INDICATOR LAMP	1,1		
16		801334328	CHARGING INDICATOR LAMP	1,1		
17		801334327	OIL PRESSURE WARNING LAMP	1,1		
18		801334113	TOUCH CONTACTOR	3,3		
19	84	801764124	HARNESS	1,1		
20	87	801764125	TRAILERING SWITCH	1,1		
21		801334111	COVER	3,3		
22		801334124	INSTRUMENT PANEL	2,2		
23		801334129	BUZZER	1,1		
24	79	812391	TRIM INDICATOR GAUGE	1,1		
25	84	812694	VERRIDE HARNESS	1,1		
26		813905	INSTRUMENT PANEL	1,1		
27	19	801334216	COVER	,1		
28	19	812390	PLUG	,1		
29	32	801764018	HARNESS	1,1		
30		801764122	INSTRUMENT PANEL ASSEMBLY	1,		
31		801764123	INSTRUMENT PANEL ASSEMBLY	,1		
32		801334401	KEY 93401			
33		801334402	KEY 93402			
34		801334403	KEY 93403			
35		801334404	KEY 93404			
36		801334405	KEY 93405			
37		801334406	KEY 93406			
38		801334407	KEY 93407			
39		801334408	KEY 93408			
40		801334409	KEY 96409			
41		801334410	KEY 96410			