



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		66418T	BRACKET (FRONT)	2		
2	10	68101	SCREW (3/8-16 X 1-3/8 IN.)	6		
3	13	35048	LOCKWASHER (3/8 IN.)	6		
4	10	37269	SCREW (7/16-14 X 2 IN.)	2		
5	13	32993	LOCKWASHER (7/16 IN.)	2		
6	11	29553	NUT (7/16-14)	2		
7		66166A	4 TRUNNION	2		
8	13	68102	LOCKWASHER (3/4 IN.)	2		
9		66284A	2 BASE-ENGINE END (FRONT)	2		
10	11	20739	NUT-JAM (3/4-16)	2		
11	14	66658	WASHER-TAB	2		
12	11	20739	NUT-JAM (3/4-16)	2		
13		805496T	BRACKET	1	(PORT)	
13		805496T	BRACKET	1	(STARBOARD)	
14	10	40097	60 SCREW (M12 X 60)	4		
15	10	57357	SCREW (7/16-14 X 2-1/4 IN.)	2		
16	13	32993	LOCKWASHER (7/16 IN.)	2		
17	11	29553	NUT (7/16-14)	2		
18		66166A	4 TRUNNION	2		
19	13	68102	LOCKWASHER (3/4 IN.)	2		
20		816326A	2 BASE-TRANSMISSION END (REA	2		
21	11	816331	NUT-JAM (3/4-16)	2		
22	14	66658	WASHER-TAB	2		
23	11	20739	NUT-JAM (3/4-16)	2		
24	54	78945	J-CLAMP	1		