



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1547	5523A18	DRIVE SHAFT HOUSING ASSEMBLY	1		
2	16	56295	STUD, DRIVE SHAFT HOUSING	2		
3	22	31704	PLUG, PIPE - DRIVE SHAFT HOUSING	1		
4	19	32652	WELCH PLUG, DRIVE SHAFT HOUSING	1		
5	23	32632	BUSHING, DRIVE SHAFT HOUSING	1		
6	11	34933	NUT, GEAR HOUSING TO DRIVE SHAFT	3		
7		54235A 2	COVER ASSEMBLY, WATER POCKET	1		
8	26	36557	SEAL, RUBBER - WATER POCKET	1		
9	27	55810	GASKET, WATER POCKET COVER	1		
10	10	28668	SCREW, WATER POCKET COVER	4		
11	32	54236	TUBE, WATER - WATER POCKET	1		
12	19	32298	PLUG, TRIM TAB HOLE - DRIVE SHAFT HOUSING	1		
13	37	60879A 1	DECAL SET, DRIVE SHAFT HOUSING	1	SERIAL 00000000-04009299	
13	37	69447A 1	DECAL SET, DRIVE SHAFT HOUSING	1	SERIAL 04009300-04193999	
13	37	70658A 1	DECAL SET, DRIVE SHAFT HOUSING	1	SERIAL 00419400-04634109	
14	37	76731A 1	DECAL SET, DRIVE SHAFT HOUSING	1	SERIAL 04634110-09999999	
15	37	76752	DECAL, DRIVE SHAFT HOUSING	1	SERIAL 04634110-09999999	
16	10	28634	SCREW, DRIVE SHAFT HOUSING	1		
17	12	20260	WASHER, DRIVE SHAFT HOUSING	1		
18	26	37259	OIL SEAL, DRIVE SHAFT HOUSING	1		
19	26	32511	OIL SEAL, GEAR CHAMBER - DRIVE SHAFT HOUSING	1		
20	15	36178A 1	SHIM, BEARING CUP TO DRIVE SHAFT HOUSING	1	AR	
21	31	35990A 1	TAPERED ROLLER BEARING ASSEMBLY	1		
22	43	59832A 2	GEAR ASSEMBLY, COMPLETE (2)	1		
23	45	55796	DRIVE SHAFT, UPPER	1		
24	25	55801	"O" RING, UPPER DRIVE SHAFT	1		
25		55758	COVER, TOP - DRIVE SHAFT HOUSING	1	SERIAL 00000000-03248347	
26	31	32575A 1	BEARING ASSEMBLY, DRIVE SHAFT	1	SERIAL 00000000-03248347	
27	23	55798	SPACER, UPPER DRIVE SHAFT	1	SERIAL 00000000-03248347	
28	24	55797	SPRING, UPPER DRIVE SHAFT	1	SERIAL 00000000-03248347	
25		61102A 1	COVER ASSEMBLY, TOP - DRIVE SHAFT HOUSING	1	SERIAL 03248348-03472477	
26	31	61100A 1	BEARING ASSEMBLY, DRIVE SHAFT	1	SERIAL 03248348-03472477	
28	24	55797	SPRING, UPPER DRIVE SHAFT	1	SERIAL 03248348-03472477	
25		62266A 1	COVER ASSEMBLY, TOP - DRIVE SHAFT HOUSING	1	SERIAL 03472478-04433199	
26	31	61100A 1	BEARING ASSEMBLY, DRIVE SHAFT	1	SERIAL 03472478-04433199	
28	15	45691A 1	SHIM, BEARING CUP TO TOP COVER	1	AR	SERIAL 03472478-04433199
25		76098A 1	COVER ASSEMBLY, TOP - DRIVE SHAFT HOUSING	1	SERIAL 04433200-09999999	
26	31	61100A 1	BEARING ASSEMBLY, DRIVE SHAFT	1	SERIAL 04433200-09999999	
28	15	45691A 1	SHIM, BEARING CUP TO TOP COVER	1	AR	SERIAL 04433200-09999999
29	25	32546	"O" RING, TOP COVER SEALING	1		
30	10	58540	SCREW, TOP COVER TO DRIVE SHAFT HOUSING	4		