



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		94993A 7	GIMBAL RING ASSEMBLY (BLACK)	1		
2	31	32538	ROLLER BEARING, GIMBAL RING	1		
3	26	32541	OIL SEAL, GIMBAL RING (OLD)	2		
4	23	39273	SPACER, GIMBAL RING (OLD)	1		
4A	23	99352	BEARING, GIMBAL RING (NYLO)	1		
5	22	69059	GREASE FITTING, GIMBAL RING	1		
6	22	74036	GREASE FITTING, GIMBAL RING	2		
7	19	<a href="#">77633Q</a>	LUBRICAP, GIMBAL RING GREASE	3		
8		77123	HINGE PIN, THREADED (WITH G)	2		
9		64947	SENDER, DUMMY (STARBOARD)	1		
10	84	19216	HARNES, DUMMY SENDER (S)	1		
11	10	46942	SCREW, HARNES ATTACHING	2		
12		99122A 2	SWITCH ASSEMBLY, TRIM LIMIT	1	NLA- ORDER 805320A 1	
13	10	37978	SCREW, SWITCH AND SENDER	4		
14	13	26996	LOCKWASHER, SWITCH AND SENDER	4		
15		57008	RETAINER, SWITCH AND SENDER	4		
16		94991A 1	STEERING LEVER (SQUARE/SPL)	1		
17		88302A 2	SHAFT, UPPER SWITCH (SQUARE)	1		
18		98262A 1	STEERING LEVER (SQUARE/SQUARE)	1		
19		98230A 1	SHAFT, UPPER SWIVEL (SQUARE)	1		
20	12	85344	WASHER (.765)	1		
21	12	32997	WASHER (.063) (SPLINED SWIVEL)	1		
21	12	98548	WASHER, (.060) (SQUARE SWIVEL)	1		
22	11	826713 23	NUT, UPPER SWIVEL SHAFT	1		
23	10	807204	SCREW, STEERING LEVER TO UPPER SWIVEL	1		
24	11	98533	NUT, STEERING LEVER TO UPPER SWIVEL	1		
25	17	52798	CLEVIS PIN, CABLE TO STEERING LEVER	1		
26	18	46950	COTTER PIN, CLEVIS PIN (NON-LOCKING)	1		
27		79146	RETAINER, CONNECTOR, TRIM LIMIT SWITCH	2		
28	10	88432	SCREW, GIMBAL RING SEE DRIVE SHAFT	2		
28	10	90126	SCREW, GIMBAL RING SEE DRIVE SHAFT	2		
29	12	34931	WASHER, GIMBAL RING SCREW	4		
30	11	862903	NUT, GIMBAL RING SCREW	2		
31	19	90887	PLUG, UPPER SWIVEL SHAFT	1		
32	85	63990	INSULATOR, TRIM LIMIT SWITCH	1		
-		805320A 1	SINGLE STATION SENDER KIT (ELECTRICAL)	AR		
-		805130A 6	DUAL STATION SENDER KIT (BLACK)	AR		