



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
--		14336A20	HYDRAULIC PUMP ASSEMBLY	1		
1		808728T	ADAPTOR	1		
2		803852	COUPLING	1		
3		18529	PUMP (INCLUDES SCREWS)	1		
4	35	89496	FILTER	1		
5	25	89498	"O" RING, MOTOR END	1		
6	25	17645	"O" RING, RESERVOIR END	1		
7		41218	DIPSTICK	1		
8		18525A	RESERVOIR	1		
9	36	861597	CAP (WITH VENT HOLE)	1		
10	10	18527	SCREW (INCLUDES "O" RING)	1		
--		17649T	MOTOR, HYDRAULIC PUMP	1		
11		17632T	END CAP W/BEARING	1		
12	10	17626	SCREW, END CAP	4		
13	25	17625	"O" RING, HOUSING	1		
14	10	17621	SCREW, FIELD FRAME	2		
15		17633	BRUSH HOLDER KIT	1		
16		17631A	BRUSH SET	1		
17		17623	ARMATURE	1		
18	12	17653	WASHER, THRUST - ARMATURE	2		
19		17624	FIELD AND FRAME	1		
20		17622	HOUSING W/BEARING	1		
-		18545A	OVERHAUL REPAIR KIT	-		
-		95353A1	THERMAL RELIEF VALVE KIT	-		
-		812499A	DOWN PRESSURE RELIEF VALVE	-		
-		812498A	UP PRESSURE RELIEF VALVE KIT	-		