



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
--	1638	3389A 7	GEAR HOUSING ASSEMBLY, COI	1	RIGHT HAND ROTATION - MERI	
--	1638	3389A 6	GEAR HOUSING ASSEMBLY, COI	1	LEFT HAND ROTATION - MERC	
--	1638	3389A 4	GEAR HOUSING ASSEMBLY, COI	1	RIGHT HAND ROTATION - MERI	
--	1638	3389A 5	GEAR HOUSING ASSEMBLY, COI	1	LEFT HAND ROTATION - MERC	
63	1638	3389A 1	GEAR HOUSING ASSEMBLY	1		
64	22	20025	PLUG, PIPE (1/4-18 THREAD)	1		
65	22	21290	PLUG, PIPE (1/8-27 THREAD)	2		
66	16	32129	STUD, GEAR HOUSING TO SI	2		
67	16	49082	STUD, GEAR HOUSING TO SI	1		
68	31	48937	ROLLER BEARING, DRIVE SF	3		*
69	22	49523	ELBOW, OIL TUBE (45 DEGREE	1		
70	10	28634	SCREW, VENT AND FILLING	2		*
71	12	20260	WASHER, SEALING - VENT A	2		*
72	31	30956	ROLLER BEARING, PROPELL	1		*
73	26	55285	OIL SEAL, PROPELLER SHAF	1		*
74	12	39701	WASHER, SPLINED - PROPELL	1		*
75	12	39698	WASHER, PLAIN - PROPELLER	1		*
76	11	49252	NUT, PROPELLER	1		*
77	44	48882	PROPELLER SHAFT	1		
78	12	48936	WASHER, PROPELLER SHAFT	1		*
79	15	20929A 1	SHIM ASSEMBLY, PROPELLER	AR		*
80	31	38146A 1	ROLLER BEARING ASSEMBLY,	1		*
81			GEAR, PROPELLER SHAFT - RE	1	RIGHT HAND ROTATION	*
82	23	48935	SPACER, PROPELLER SHAFT -	1	RIGHT HAND ROTATION	
83			GEAR, DOUBLE BEVEL - PROPI	1	RIGHT HAND ROTATION	*
84	23	48934	SPACER, PROPELLER SHAFT -	1	RIGHT HAND ROTATION	
85	12	49808	WASHER, PROPELLER SHAFT	1	LEFT HAND ROTATION	*
86	23	49809	SPACER, PROPELLER SHAFT -	1	LEFT HAND ROTATION	
87			GEAR, DOUBLE BEVEL - PROPI	1	LEFT HAND ROTATION	*
88	23	48935	SPACER, PROPELLER SHAFT -	1	LEFT HAND ROTATION	
89	43	48949	GEAR, PROPELLER SHAFT	1	LEFT HAND ROTATION	
90	31	38135A 1	ROLLER BEARING ASSEMBLY,	1		*
91	12	48933	WASHER, PROPELLER SHAFT	1		*
92	11	39094	NUT, PROPELLER SHAFT	1		*
93	23	48932	SPACER, BEARING RETAINER	1		
94	11	48931	NUT, BEARING RETAINER	1		*
95		48942	ANCHOR STUD, BEARING RET	1		
96	25	30224	"O" RING, ANCHOR STUD	1		*
97	12	48930	WASHER, ANCHOR STUD	1		*
98	53	48928	RING, SNAP - ANCHOR STUD T	1		*
99		48929	COVER, GEAR HOUSING	1		