



2547

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		18896A	COVER KIT	1		
2		79022	MARKER	1		
3	10	37572	SCREW, (.190-32 x .380)	2		
4	12	72761	WASHER	2		
5	19	45907	PLUG, (Yellow)	1		
6	11	52901	NUT, (.625-18)	1		
7	12	68229	WASHER	1		
8	271	859238T	4 FLYWHEEL ASSEMBLY	1	SN# 0T800999 & Below	
8	271	859238T15	FLYWHEEL	1	SN# 0T801000 & Up	
9	398	858404T	4 STATOR	1	SN# 0T599000 & Up	
9	398	858404T	3 STATOR ASSEMBLY	1	SN# 0T598999 & Below	
10	10	90045	SCREW, (#10-32 x 1.375)	5		
11	13	26996	LOCKWASHER, (#10)	5		
12		96455A18	TRIGGER ASSEMBLY	1		
13		74897	PIVOT	1		
14	11	45076	NUT, (#10-32)	1		
15		76035	ROD	1		
16		62459	BALL JOINT ASSEMBLY	1		
17	50	79472T	2 STARTER MOTOR	1	SN# 0T469023 & Up	
17	50	884238T	STARTER MOTOR	1	SN# 0T409000 THRU 0T469022	
17	50	79472	1 STARTER MOTOR	1	SN# 0T408999 & Below	
18		56703	COLLAR	2		
19		68042	STOP, Rubber	2		
20	10	69035	SCREW AND LOCKWASHER, (.250)	1		
21	84	93388A	1 CABLE ASSEMBLY, Black	1		
22	13	26992	LOCKWASHER, (.250)	1		
23	11	94330	NUT, (.250-20)	1		
24		NSS	NOT SOLD SEPARATE, Decal-In-	1		
25	37	827282	2 DECAL, Warning, High Voltage	1		
26	37	881865	DECAL, Caution-Start in Gear	1	(Start In Gear)	