



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		883078A 4	AIR INJECTOR KIT	6		
-	26	804875	SEAL KIT	1		
2	12	828694A 1	WASHER ASSEMBLY, Cupped, Cl	6		5
-		NSS	NOT SOLD SEPARATE, Fuel Rail,	1		
3		884429T16	FUEL RAIL (PORT)	1		
4		884430T06	FUEL RAIL (STARBOARD)	1		
5	54	804830	CLAMP	4		
6	54	804831	CLAMP	4	SN# 0T979999 & Below	
6	54	804831 1	CLAMP	4	SN# 0T980000 & Up	
7	54	804832	CLAMP	2		
8	54	880816	CLAMP	1		
9	25	804530	O-RING KIT	1		
10	19	804835	PLUG	1		
11	22	804836	FITTING	1		
12		804837	VALVE ASSEMBLY, Air	1		
13		883542	VALVE ASSEMBLY, Fuel	1		
14	19	804839001	CAP	2	SN# 0T979999 & Up	
14	22	805515	CAP, Brass	2	SN# 0T980000 & Up	
15	25	804840	O-RING KIT	1		
16	25	804529	O-RING KIT	1		
17		804533	DIAPHRAGM ASSEMBLY	1		
18	24	804534	SPRING	1		
19	25	804536	O-RING	1		
20		804535	COVER	1		
21		804526	SCREW PACKAGE, (2 Per) (M5	4		
22		804532	O-RING KIT (16 per kit)	1		
23		804525	SCREW PACKAGE, (M5 X 8) (2	15		
24	32	804827	HOSE, Fuel Balance	1		
25	32	889310	HOSE, Fuel Supply, To Vapor Se	1		
26	32	889311	HOSE, Fuel By-Pass	1		
27		804528	INJECTOR, Fuel	6		
28	25	803987	SEAL	1	SN# 0T979999 & Below	
28		804532	O-RING KIT	1	SN# 0T980000 & Up	
29	11	826292	NUT, (M10)	4		
30	54	859376	CLIP, CONDUIT	4	SN# 1B226999 & Below	
30		828791	CLIP	4	SN# 1B227000 & Up	
31	16	858778	STUD, (M10 x 91)	4		
32	54	856880	CLAMP, (15.3)	1		
33	26	888852	SEAL, Fuel Director	1		
-		854198A04	POWERHEAD	1	(200)	
-		87369A04	POWERHEAD	1	(225)	