



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	3401	8718A	1 TRANSOM BRACKET (STARBOARD)	1		
2	3400	8716A	5 TRANSOM BRACKET (PORT)	1		
3	22	98727	GREASE FITTING	1		
4		99170A	1 TILT TUB	1		
5	11	90068T	NUT, TILT TUBE (1"-14)	1		
6	25	45711	"O" RING, TILT TUBE	1		
7	13	88750	WAVE WASHER, TILT TUBE	2		
8	11	56041	NUT, TILT TUBE (7/8-14)	1		
9	10	67755	1 BOLT, MOUNTING BRACKET TO	4		
10	12	28421	WASHER, MOUNTING BRACKET	4		
11	11	35000	NUT, MOUNTING BRACKET BOL	4		
12	10	96930A	1 BOLT ASSEMBLY, TILT LOCK	1		
13	11	23161	NUT, BOLT	1		
14		99629A	2 TILT LOCK LEVER	1		
15	13	99611	WAVE WASHER	1		
16	23	65830	BUSHING, TILT LEVER	2		
17		99633	1 KNOB, TILT LOCK LEVER	1		
18	17	99615	GROOVE PIN	1		
19	24	99622	SPRING	1		
20	17	99604	GROOVE PIN	1		