



4850

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	822462T 1	STARTER MOTOR	1		
2	10	96566 1	THRU BOLT	1		
3		90643	DRIVE KIT	1		
4		68575 3	DRIVE ASSEMBLY	1		
5		823639 2	DRIVE CAP	1		
6		96565 1	ARMATURE	1		
7		811901 1	COMMUTATOR CAP	1		
8		75384	BRUSH/SPRING KIT	1		
9		61787	HOLDER	1		
10		F15158	SCREW	2		
11	13	26392	LOCKWASHER, (.250)	1		
12	11	64015	NUT, (.250-20)	1		
13	84	88439A 9	BATTERY CABLE, Positive	1		
14	10	40011153	SCREW, (M8 x 45)	3		
15		NSS	NOT SOLD SEPARATE, Decal-W:	1		
16		823989	BRACKET, Oil Tank	1		