



4861

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		19653T 3	EXHAUST PLATE ASSEMBLY	1		
2	21	817519A 1	CHECK VALVE, Drain	1		
3	17	23784	PIN, Dowel	4		
4		881899	UPPER MOUNT	1		
5	10	40011153	SCREW, (M8 x 45)	4		
6	10	42973	BOLT, (M12 x 154)	2		
7	12	93416 1	WASHER, Neoprene	2		
8	12	28421	WASHER, (1.5 x 3.05 x 0.13) SS	2		
9	11	859129	NUT, (M12)	2		
10	10	40011158	SCREW, (M8 x 70)	1		
11	27	812866	GASKET	1	(Not Used on Jet Models)	2
12	23	48237	BUSHING	1	(Not Used on Jet Models)	
13		815639A 10	SHIFT SHAFT	1	(Upper)(Long)(Not Used on Jet Models)	
13		812891A 7	SHIFT SHAFT	1	(Upper)(Long)(Electric)(Not Used on Jet Models)	
13		815639A 9	SHIFT SHAFT	1	(Upper)(Long/LL)(Manual)(Not Used on Jet Models)	
14		812872A 2	SHIFT LINK	1	(Not Used on Jet Models)	
15	23	48475	BUSHING	1	(Not Used on Jet Models)	
16	11	40138 6	NUT, (M6)	1	(Not Used on Jet Models)	
17	32	881200 2	WATER TUBE	1	(Short)	
17	32	881200 1	WATER TUBE	1	(Long)	
18	25	93221002	GROMMET	1		2
19		19655 1	EXHAUST TUBE	1		
20	10	40011153	SCREW, (M8 x 45)	4		
21		812886001	SEAL	1		
22		99019	CLAMP	1		
23		42941001	SEAL, Water Tube	1	(Upper)	2
24	10	40011155	SCREW, (M8 x 55)	2		
-	27	812867A97	GASKET SET	1		