



EXHAUST PLATE

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		42954A 1	PLATE ASSEMBLY, EXHAUST	1		
2	17	23784	DOWEL PIN	4		
3		42939	SEAL, LOWER COWL	1		
4		42949 1	MOUNT, UPPER (LONG)	1		
4		44344 1	MOUNT, UPPER (X-LONG)	1		
5	10	40113 50	SCREW, UPPER MOUNT TO EXH-	4		
6	10	42974	SCREW, UPPER MOUNT	2		
6	10	12515	SCREW, UPPER MOUNT (HANDL	2		
7	12	93416	WASHER, UPPER MOUNT SCRE	2		
8	12	28421	WASHER, UPPER MOUNT SCRE	2		
9	11	90099	NUT, UPPER MOUNT SCREW	2		
10	22	99664	ELBOW, EXHAUSE PLATE	1		
11	10	40111 35	SCREW, EXHAUSE PLATE	2		
11	10	40107 70	SCREW, EXHAUSE PLATE	1		
12	27	43008	GASKET, EXHAUST PLATE	1		10
13		42966T	EXHAUST TUBE	1		
14	10	40107 35	SCREW, EXHAUST TUBE TO PL	6		
15		42962	SEAL, EXHAUST TUBE	1		
16	32	43014 1	WATER TUBE (LONG)	1		
16	32	43014 2	WATER TUBE (X-LONG)	1		
17		99019	CLAMP, WATER TUBE SEAL	1		
18		42941	SEAL, WATER TUBE (UPPER)	1		10
19	10	40107 50	SCREW, CLAMP	2		
20	25	93221	GROMMET, WATER TUBE	1		10
21		42953A 1	BRACKET ASSEMBLY, COWL (LO	1		
22		43405	SEAL, LOWER COWL BRACKET	1		
23	10	40095 55	SCREW, LOWER COWL BRACKE	3		
24	23	48237	BUSHING, SHIFT SHAFT	1		
25		79932A 9	SHIFT SHAFT ASSEMBLY (UPPE	1		
26	23	42994	BUSHING, SHIFT SHAFT	1		
27		42912 1	SHIFT LINK	1		
28	13	29720	WAVE WASHER, SHIFT SHAFT	1		
29	12	24664	WASHER, SHIFT SHAFT	1		
30	11	40063 4	NUT, SHIFT SHAFT	1		
31	23	43041	SPACER, SHIFT SHAFT (LONG)	1		
31	23	11289	SPACER, SHIFT SHAFT (X-LONG)	1		
32		43053	COUPLING, SHIFT SHAFT (NON F	1		
33		43585	COUPLING, SHIFT SHAFT (POWE	1		
.	27	43004A86	GASKET SET			