



15223

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	1667	9011A 7	GEAR HOUSING ASSEMBLY, Blar	1		
-	1667	9011A 9	GEAR HOUSING ASSEMBLY, Gra	1		
1	1667	9011A 6	GEAR HOUSING ASSEMBLY, BI	1		
1	1667	9011A 8	GEAR HOUSING ASSEMBLY, G	1		
42	31	30894A 1	BEARING SET, Cup And Cone	1		
43	43	12634A 2	FORWARD GEAR ASSEMBLY	1		
44	31	30895	ROLLER BEARING	1		
45		12239A 1	CAM FOLLOWER ASSEMBLY	1		
45A	30	44530	BALL	3		
46	24	30622	SPRING	1		
47	52	814756	CLUTCH	1		
48	17	30632	PIN, Cross	1		
49	24	30893	SPRING	1		
50	44	12238T	PROPELLER SHAFT	1		
51	43	12635	REVERSE GEAR	1		
52		12596A 2	BEARING CARRIER ASSEMBLY	1		
53	25	97386	O-RING	1		2,15
54	31	30956	ROLLER BEARING	1		
55	26	76868	SEAL, Inner	1		15
56	26	70081	OIL SEAL, Outer	1		15
57	31	12578	ROLLER BEARING	1		
58	12	12577	THRUST WASHER	1		
59	31	12576	THRUST BEARING	1		
60	10	40003 54	SCREW, (M8 x 30)	2		
61	12	40023 17	WASHER	2		
62	15	44491A 1	SHIM SET	1		
63		13191A 1	THRUST HUB AND WASHER AS:	1		
64	14	816629	TAB WASHER	1		
65	11	52707A 1	NUT, Propeller	1		
-	26	43035A 3	GEAR HOUSING SEAL KIT	1		
-	27	43004A90	GASKET SET	1		