



| Parts List | | | | | | |
|------------|-------|----------|----------------------------|-----|---------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| - | | 92975A 6 | HYDRAULIC PUMP ASSEMBLY | 1 | | |
| 1 | 25 | 48171 | "O" RING, HYDRAULIC PUMP | 4 | | |
| 2 | 392 | 8317 | VALVE BODY AND GEAR ASSE | 1 | | |
| 3 | 10 | 69570 | SCREW, VALVE BODY TO RESI | 8 | | |
| 4 | 392 | 7735 | SEAL, RESERVOIR TO VALVE E | 1 | | |
| 5 | 392 | 7731 | RESERVOIR ASSEMBLY (PLAS | 1 | | |
| 6 | 392 | 7732 | WASHER, THRUST - ARMATUR | AR | | 3 |
| 7 | 392 | 7729 | ARMATURE, FIELD AND FRAM | 1 | | |
| 8 | 392 | 8261 | FIELD AND FRAME ASSEMBLY | 1 | | |
| 9 | 392 | 7730 | BALL, COMMUTATOR END PLA | 1 | | |
| 10 | 392 | 8262 | PLATE ASSEMBLY, COMMUTA | 1 | | |
| 11 | 392 | 2941 | BRUSH SET, COMMUTATOR | 1 | | |
| 12 | 392 | 2529 | SPRING SET, BRUSH TENSION | 1 | | |
| 13 | 392 | 7733 | BOLT SET | 1 | THRU - PLATE AND FRAME TO | |
| 14 | 392 | 7727 | COUPLER AND SHAFT | 1 | | |
| 15 | 392 | 7728 | FILL PLUG, RESERVOIR | 1 | | |