


D4-180I-B, D4-180I-C, D4-180I-D, D4-180I-E, D4-210A-A, D4-225A-B, D4-210I-A, D4-210I-B, D4-225I-B, D4-225A-C, D4-225A-D, D4-225I-C, D4-225I-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-260D-B, D4-260D-C, D4-260D-D, D4-260I-A, D4-260I-B, D4-260I-C, D4-260I-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-300D-A, D4-300D-C, D4-300I-A, D4-300I-C, D4-300I-D, D4-225A-E, D4-225I-E, D4-260A-E, D4-260D-E, D4-260I-E, D4-300A-E, D4-300D-E, D4-300D-D, D4-300I-E



26430

D4-180I-B, D4-180I-C, D4-180I-D, D4-180I-E, D4-210A-A, D4-225A-B, D4-210I-A, D4-210I-B, D4-225I-B, D4-225A-C, D4-225A-D, D4-225I-C, D4-225I-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-260D-B, D4-260D-C, D4-260D-D, D4-260I-A, D4-260I-B, D4-260I-C, D4-260I-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-300D-A, D4-300D-C, D4-300I-A, D4-300I-C, D4-300I-D, D4-225A-E, D4-225I-E, D4-260A-E, D4-260D-E, D4-260I-E, D4-300A-E, D4-300D-E, D4-300D-D, D4-300I-E

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3801296	1	Starter motor, exch • parts not sold separately	12V, SOLAS
	3801297	1	Starter motor, exch • parts not sold separately	24V, SOLAS
2	21389274	1	Gasket	
3	21380910	1	Gasket	
4	21308512	3	Insulating bushing	
5	845884	3	Spacer sleeve	
6	973246	3	Hexagon screw	
7	983714	1	Hexagon nut	
8	983715	1	Hexagon nut	negative pole
9	857180	1	Spacer nut	positive pole
10	946670	1	Flange screw	
11	855798	1	Protecting sleeve	
12	3818845	1	Starter relay	12V
	3818856	1	Starter relay	24V
13	948702	1	Cable tie	
	948211	1	Cable tie	
14	996153	1	Chassis ground cable	Do not use with transient protector
15	21923306	1	Wiring harness kit	Transient protector, alternative to chassis ground cable