



11311

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	856609	1	Water pump • components		
2	856610	2	Gasket		
3	955536	4	Hexagon screw		
4	856611	1	Hose		
5	(856612)	2	Hose attachment		Obsolete part
6	961666	4	Hose clamp		
7	855283	1	Pulley		
8	955656	4	Hexagon screw		
9	941907	4	Spring washer		
10	856513	1	Sea water pump •	12499	
11	976644	3	Hex. socket screw		
12	942336	3	Spring washer		
13	856155	1	Bracket		Early type
	857356	1	Stay		Late type
14	940116	2	Hexagon screw		
15	941909	2	Spring washer		Early type
16	826422	1	Rubber bushing		
17	955523	1	Hexagon screw		
18	960141	1	Washer		
19	941907	1	Spring washer		Early type
20	952077	1	Plug		Installed on the inlet manifold.
21		1	thermostat housing •	12484	
22	835417	1	Gasket		
23	955538	2	Hexagon screw		
24	942336	2	Spring washer		
25	(855983)	2	Coolant pipe		Obsolete part
26	855984	2	Coolant pipe	12483	
27	842913	4	Sealing ring		
28	858986	4	Sealing ring		
29	847108	2	Pipe retainer		
30	856452	2	Brace		
31	965175	2	Flange screw		
32	(856529)	1	Hose	12483	Obsolete part
33	961672	2	Hose clamp	12483	
34		1	heat exchanger and installation components	12483	
35	857051	1	Hose		
36	952973	X	Hose		L=100mm
37	856505	X	Hose		
38	961669	12	Hose clamp		
39	(855987)	1	Coolant pipe		Obsolete part
40	(855986)	1	Coolant pipe		Obsolete part
41	965175	8	Flange screw		
42		1	oil cooler		See group 2A
43		1	connection		See group 2A
44	(856263)	1	Bracket		Obsolete part
45	(856314)	1	Clamp		Obsolete part
46	946440	1	Flange screw		
47	955526	2	Hexagon screw		
47A	941907	2	Spring washer		
48		1	connection		See group 2A
49	967191	1	V-belt, drive belt kit		See group 3
					L=2x1250mm
50	(856223)	1	Coolant pipe		Obsolete part, See group 4A
51	(856224)	1	Coolant pipe		Obsolete part, See group 4A
52		2	exhaust manifold	12491	