

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	846638	1	Injection pump		
	3803683	1	Injection pump, exch		Exchange unit
				02C-0737	
2	821134	1	Lever		REPL BY 848677
	848677	1	Lever		
3	239056	1	Spring		NOT FOR ENGINE WITH STOP SOLENOID.
4	239059	1	Cover		NOT FOR ENGINE WITH STOP SOLENOID.
5	466398	1	Pressure equalizer		
6	18838	1	Gasket	IK	
7	953261	4	Stud		
8	940097	4	Washer		
9	942299	4	Nut		
10	842467	1	Gear		
11	420080	1	Intermediate section		
12	465260	1	Hub		
12A	925256	1	O-ring		
13	411301	1	Lock washer		
14	940161	4	Screw		(921828)
15	471190	1	Cover		
				02C-1900	
16	960630	3	Plug		
17	18838	3	Gasket	IK	
18	940114	2	Screw		
19	942336	2	Spring washer		
20	940097	2	Washer		
21	845151	1	Fuel pipe		
22	25167	2	Hollow screw		
23	957178	4	Gasket		
24	844966	1	Fuel pipe		
25	25167	2	Hollow screw		
26	957178	4	Gasket		
27	404279	2	Clamp		
28	950048	1	Screw		
29	955825	1	Nut		
30	465399	1	Oil feed pipe		
31	48634	1	Hollow screw		
32	947281	2	Gasket		
33	329638	1	Elbow union		
34	954364	1	Fitting		
35	954356	1	Cap nut		
36	465584	1	Bracket		
37	950045	2	Screw		
38	940374	1	Clamp		
39	844864	1	Fuel pipe		
40	16496	1	Hollow screw		
41	957178	3	Gasket	IK	
42	35096	1	Overflow valve		
43	466919	2	Anchorage		
44	404279	2	Clamp		
45	950046	2	Screw		
46	955534	2	Screw		
47	942336	2	Spring washer		
48	844861	1	Fuel pipe		
49	25167	1	Hollow screw		
50	18838	2	Gasket	IK	
51	846590	1	Leak-off line		

